

Model DS2000

Single Channel Hygrometer

A complete on-line solution for continuous measurement of dewpoint in process gas and compressed air, offering powerful functionality via a simple interface.

- · Advanced functionality with user-friendly design
- Accuracy ±2°C Dewpoint
- Automatic Calibration
- RS485 serial communications
- 2 Independent, fully programmable alarm relays
- · Linear retransmission signal of current or voltage
- Cable Length of up to 1km to sensor
- Calibration Traceable To National & International Standards



The dewTEC Model DS2000 from Alpha Moisture Systems is a single channel, online hygrometer designed to accurately measure dewpoint in process gases and dry compressed air. This panel mounted DIN style dewpoint meter combines advanced digital technology with the industry leading ultra high capacitance aluminium oxide sensors - the acknowledged industry benchmark for trace moisture measurement in process gases.

The combination of advanced display electronics and full specification sensors makes this the unit of choice for a wide range applications due to it's flexibility and high configurability and ease of use through its menu driven operation. The instrument can be factory configured to order to read in °C dewpoint, °F dewpoint, ppm(V), g/m^3 or lb/MMSCF.

The measured dewpoint is displayed by means of a large 5½ digit, seven segment LED display. Model DS2000 also offers two independent, fully user programmable alarm contacts and open collector outputs to provide all the versatility required for any application. The factory set, analogue, current or voltage output, that is linear with dewpoint, is available as well as RS485 serial connection with 1-99 address settings. The <code>dewTEC</code> DS2000 is a fully self-contained display system in 1/8 DIN panel mounted case providing front panel protection to IP66 (NEMA 4).

The dewTEC DS2000 can be supplied together with any one of a range of dedicated, ultra high capacitance, sensors incorporating automatic calibration and covering an overall range from -110°C to +20°C dewpoint. The sensor has been conditioned for long term stability so ensuring a long

and trouble free service life. Additionally the high sensitivity and linear output of the sensor allow up to 1km cable length between sensor and <code>dewTEC DS2000</code> instrument. The sensor is ATEX certified for intrinsic safety so can be used in hazardous environments with a suitable Zener barrier in the safe area.

The long lasting sensing element offers excellent sensitivity, repeatability and response speed - especially on dry down. Each unit is calibrated to $\pm 2~^{\circ}\mathrm{C}$ accuracy and is supplied with a calibration certificate traceable to International Humidity Standards.

The dewTEC DS2000 incorporates two fully programmable alarm relays to control external devices, including process high, process low, direct acting, reverse and logical OR. The alarms can be independently set across the full operating range of the sensor with variable hysteresis for the chosen engineering unit.

The dewTEC Model DS2000 Dewpoint Hygrometer is supplied fully configured according to the customer's specifications and ready to use, with calibration certification traceable to national and international standards, instruction manual and 2 meters of connecting cable as standard.

An optional sensor holder can be ordered with the instrument. Additional sensor cable upto 1000m can be ordered separately.

Alpha Moisture Systems

Alpha House, 96 City Road Bradford, BD8 8ES England







Specifications

Model DS2000 - Dewpoint Hygrometer

Type: Red/green, 7-segment, 5-digit primary display, 1-digit secondary display. Height: 18mm (0.71inches) primary display, 7mm (0.3 inches) secondary display Annunciators: Alarm 1 and Alarm 2 status

Dewpoint Range: From -110°C to +20°C Accuracy: ± 2°C over full range Operating Temperature: -10°C to +50°C Storage Temperature: -50°C to +70°C

Operating Humidity: 10-90% RH non-condensing Mechanical Connections: M14x1.25mm pitch Electrical Connection: Male coaxial plug

Approvals: CE, Atex -

HYGROMETER INPUT

Sampling Rate: 10Hz Resolution: 14-bits

Sensor short circuit detection: Detected within two seconds. All alarms become

active

TRANSISTOR OUTPUTS

Type: NPN open collector. Output 1 tied to Alarm 1. Output 2 tied to Alarm 2.

RELAY OUTPUT 1

Contact Type: Single pole, double throw Rating: 2A resistive, 120/240V, 50/60Hz

Lifetime: >500,000 operations at rated voltage/current

Isolation: Inherent

RELAY OUTPUT 2

Contact Type: Single pole, double throw Rating: 2A resistive, 120/240V, 50/60Hz

Your Local Distributor

Lifetime: >500,000 operations at rated voltage/current

Isolation: Inherent

LINEAR (RE-TRANSMITTED) OUTPUT (VOLTAGE OR CURRENT IS A FACTORY SET OPTION)

Ranges Available: 0-5V, 1-5V, 0-10V, 2-10V, 0-20mA and 4-20mA

Accuracy: ±0.5% max of display value

Load Impedance: 500. max for mA ranges, 500. min for voltage ranges

SERIAL COMMUNICATIONS

Type: Serial asynchronous, UART to UART

Data Format: Open ASCII; one start bit, even parity, seven data bits and one stop bit.

Physical Layer: RS485 Maximum Number of zones: 99

Baud Rate: Selectable - 1200, 2400, 4800 or 9600

PERFORMANCE

Reference Conditions

Supply Voltage: 90 - 264V, 50Hz Power Consumption: 7.5VA max

Operating Conditions

Ambient Temperature: 0°C to +55°C Relative Humidity: 10 - 95% non-condensing

ENVIRONMENTAL

Approvals: CE

EMC: Certified to EN61326 Safety: Complies with EN61010-1 Front Panel Seal: To IP66

PHYSICAL

Dimensions: Height - 48mm


Width - 95mm

Depth - 110mm without sensor connector.

Weight 0.21 kg max.

Mounting: Panel-mount; press-fit fixing. Panel cut out – 45mm x 92mm.

Terminals: Screw type



Ordering Information Model DS2000-[XX]-[X]-[X]-[XX]-[XX]-[XX] RANGE = XX RANGE = XA SR: -110°C to -20°C (-166°F to -4°F) dewpoint PL: -100°C to 0°C (-148°F to +32°F) dewpoint RD: -80°C to -20°C (-112°F to +32°F) dewpoint -80°C to 0°C (-112°F to +32°F) dewpoint -80°C to +20°C (-112°F to +68°F) dewpoint DISPLAY UNITS = X °C Dewpoint °F Dewpoint ppm(V) lb/MMSCF G: g/m³ RETRANSMISSION OUTPUT = X Voltage Output A: Current Output ALARM 1 CONFIGURATION = XX HD: High Alarm, Direct action (normally de-energised relay) HR: High Alarm, Reverse action (normally energised relay) LD: Low Alarm, Direct action (normally de-energised relay) LR: Low Alarm, Reverse action (normally energised relay) ALARM 2 CONFIGURATION = XX HD: High Alarm, Direct action (normally de-energised relay) HR: High Alarm, Reverse action (normally energised relay) LD: Low Alarm, Direct action (normally de-energised relay) LR: Low Alarm, Reverse action (normally energised relay) SENSOR HOLDER N: None 4: 1/4" Swagelok® Stainless Steel Compression Fitting B: 1/8" Swagelok® Stainless Steel Compression Fitting 6: 6mm Swagelok® Stainless Steel Compression Fitting Example: To order device with range -80°C to -20°C dewpoint, with retransmission set to current output, both alarms to trip on rising dewpoint with normally de-energised

relays and sensor holder with 1/4" Swagelok® fittings, order as

Model DS2000 - RD - C - A - HD - HD - 4